LEDSON Scene Light 24W

INSTALLATION INSTRUCTIONS


Preliminary Steps


- 1. Read the instructions carefully and study diagrams before installing the light
- 2. Check with state and local authorities for laws governing usage and proper mounting
- 3. Disconnect ground connection from battery (marked "-") to avoid accidental short circuits before attempting to connect electrical wires
- 4. Route new wires along existing wiring, use tape if necessary
- 5. When running wires through the firewall, keep them away from moving parts

Mounting Lights

- 1. Drill 7 mm holes for screw placement on the surface where you would like to fix the light
- 2. Use the bolt to fasten the light, add the locking washer and tighten the bolt
- 3. The rubber block can be added to change the mounting angle according to the installation height
- 4. Wiring:

Red: "+" / Black: "-"





Warning:

- 1. Works under the specified voltage (DC9-36V)
- 2. This light becomes hot under continuous use. Don't remove or touch the casing for at least 30 minutes after turning the lamp off
- 3. Keep heat-sink clean and exposed to maintain air flow